

SCT 3000 Software Upgrade Kit

Replacement Instruction

34-ST-33-45

Date: 4/08

To Upgrade Your SCT 3000 Software

Background

The upgrade SCT 3000 Software Upgrade Kit is a direct replacement for earlier versions of the SCT 3000 Application you installed in your PC.

About the Upgrade Kit

The SCT 3000 Software Upgrade Kit SCT 3000 consists of the latest version of the SCT 3000 application software on CD and/or 3.5" floppy diskettes, and this kit instruction. The CD is the source needed are to upgrade earlier versions of the SCT 3000 application. This kit instruction provides the upgrade procedure.

The SCT 3000 application version in this upgrade kit is compatible with the following Windows operating systems:

- Windows 98
- Windows 2000
- Windows XP

Note: This version of the SCT 3000 does not run under Windows 3.1 or 95

Upgrade Procedure

The procedure on the following pages outline the steps for uninstalling the existing SCT 3000 application now on your PC and then installing (upgrading) the new version of the SCT 3000.

Note: The SCT 3000 CD contains the installation utility on them. Once the installation utility is started, on-screen prompts should guide you through the program to install (upgrade) the SCT 3000 application software. You must follow the setup procedure. You cannot simply copy the files from the setup disks to your hard drive.

Continued on next page

SCT 3000 Software Upgrade Kit Procedure

Procedure

Follow the procedure below to upgrade the SCT 3000 application software on your PC.



IMPORTANT

If you are installing this version of the SCT 3000 application software and you have a previous version of the SCT 3000 on your computer, you must uninstall the previous version manually.

To remove the previous version:

Go to the **Start menu > Settings > Control Panel > Add/Remove Programs**, and then **select SCT3000** as the program to remove. Follow the prompts to remove the program.

Uninstalling the SCT 3000 will not delete any device-specific files from your PC. Backups of all files should always be maintained.

Step	Action
1	It is recommended that you close any other applications you have running in Windows as these can greatly increase the time for upgrading your SCT 3000 application.
2	Using the CD in the upgrade kit – Insert the SCT 3000 CD into the CD-ROM drive of the PC.
3	From the Windows 98/2000 or XP desktop display: <ul style="list-style-type: none">- Click on the Start button- Select: Settings, Control Panel, Add/Remove Programs- From the Install/Uninstall tab card, select “Install” and follow directions (press next).
4	Wait for the Honeywell SCT 3000 Setup screen to appear and the setup wizard to finish. Note: <ul style="list-style-type: none">• Setup detects various conditions (hardware & software) that may affect the SCT 3000 Program or Drivers (if applicable). It is recommended that you follow the directions provided by setup.• Setup also recommends that you uninstall any previously installed versions of the SCT 3000 application.• It is highly recommended that you do not run the setup program while the SCT 3000 application is running.

Continued on next page

SCT 3000 Software Upgrade Kit Procedure, Continued

Step	Action
5	<p>The Setup screen welcomes you to the SCT 3000 Setup Program and prompts you as to whether or not you wish to continue:</p> <ul style="list-style-type: none">- Click Next if you wish to continue and install the SCT 3000 application program.- Click Cancel to quit the SCT 3000 Setup program and return to the Windows desktop.
6	<p>If you clicked Next in Step 5, the Software License Agreement screen appears. Read the Software License Agreement carefully.</p> <ul style="list-style-type: none">- Click Yes if you wish to continue and install the SCT 3000 application.- Click No to quit the Setup program and return to the Windows desktop.- Click Back to go back to the Setup screen.
7	<p>If you clicked Yes in Step 6, a User Information dialog box appears:</p> <ul style="list-style-type: none">- Enter your Name and Company in the specific fields.- Click Next if you wish to continue and install the SCT 3000 application.- Click Cancel to quit the SCT 3000 Setup program and return to the Windows desktop.- Click Back to go back to the Software License Agreement screen.
8	<p>If you selected Next in Step 7, a Choose Destination Location dialog box appears and indicates the destination directory:</p> <ul style="list-style-type: none">- Click Next if the Destination Directory is correct.- Click Browse to open the Choose Directory dialog box and choose a Destination Directory.
9	<p>If you selected Next in Step 8, a Select Program Folder dialog box appears indicating which Program Folder the Setup program will add program icons to. You may type a new folder name, or select one from the existing folders list.</p> <ul style="list-style-type: none">- Click Next to continue.- Click Back to return to Step 8.
10	<p>If you selected Next in Step 9, a Setup dialog box appears and indicates the program files being installed.</p> <ul style="list-style-type: none">- Click Cancel to exit Setup mode (if desired). <p>Note: After program files have been installed you will be given an opportunity to Resume or Exit setup.</p>

Continued on next page

SCT 3000 Software Upgrade Kit Procedure, Continued

Step	Action
11	After the installation of the SCT 3000 files are complete, the setup program will update the: <ul style="list-style-type: none">• Registry• Registration Information• System DLLs• SCT DLLs and OCX files
12	Wait for the <i>Setup Complete</i> dialog box to appear.
13	Remove the CD or diskette from the disk drive. Click Finish to exit. You must restart the computer before you can run the SCT 3000 application.
14	SCT 3000 upgrade is complete.
