

MC Toolkit Web Download and Installation Instructions

Document

Form: 34-ST-33-59
Effective: 11/07
Supersedes: None

Summary

This instruction is to aid you in the installation of MC Toolkit from the following Honeywell website:

<http://hpsweb.honeywell.com/Cultures/en-US/Products/Instrumentation/configtools/mctoolkit/SoftwareDownloads/documents.htm>

MC Toolkit Web download

The above web site contains the following items listed in Table 1.

Table 1 Web Components

Description	File/s	Quantity
MC Toolkit Installation setup	Setup.exe	1
MCToolkit DD File – Qx/200x	Entire HCF DD Release folder with subfldrs and files needed for the MC toolkit - SDC 625 program	All the files

Installing the Toolkit

Case 1: Upgrade the MC toolkit software and the DD files

To upgrade the MC toolkit software and the DD files on the existing 256 MB Memory Card on the Host PDA, follow the steps in Table 2.

Table 2 Installation Instructions

Step	Action
1	If the Host PDA has any or all of the previously installed following programs, follow the steps below to remove these programs from the PDA. <ul style="list-style-type: none">A. Honeywell MC ToolkitB. MC ToolkitC. SDC

Step	Action
D. Honeywell SDC E. CFG_MCT F. Honeywell CFG_MCT	Follow the Steps below: <ol style="list-style-type: none"> a. Select Start/Settings/System/Memory/Remove Programs b. Select the above programs one by one(If a program is not listed, that means it was not installed on this PDA before) c. Select Remove, select Yes on the Remove Program dialog d. Soft Reset the PDA
2	Setup ActiveSync connection between the Host PDA and the Desktop
3	If the desktop PC has any or all of the previously installed following programs, follow the steps below to remove these programs from the PC. <ol style="list-style-type: none"> A. Honeywell MC Toolkit B. MC Toolkit C. SDC D. Honeywell SDC E. CFG_MCT F. Honeywell CFG_MCT <p>Steps:</p> <ol style="list-style-type: none"> a. Select Start/Settings/Control Panel/Add Remove Programs b. Select the above programs one by one(If a program is not listed, that means it was not installed on this PC before) c. Select Change/Remove d. On the "Welcome Dialog" select "Remove", hit Next. e. Click Yes on "Do you want to completely remove..." prompt.
4	From the Web site listed under Summary <p>Save the following 2 items into your pc</p> <ol style="list-style-type: none"> 1. MCToolkit DD File – Qx/200x 2. MC toolkit Installation Setup <p>Follow the steps below:</p> <ol style="list-style-type: none"> a. Unzip item 1 to a folder named Release on the PC. b. Unzip item 2 to a folder on the PC (ex: MCT) - Setup.exe file will be extracted c. With the Activesync connection in place between PC and the PDA, replace the entire Release folder under Honeywell SDC and SDC on the PDA with the one on the PC (PDA path: Start/Programs/File Explorer/My Device/SD Card /)

Step	Action
	d. Run Setup.exe saved in step b on the PC
5	Follow the instruction 6 or 7 depending upon the Host PDA OS Version
6	If it is Windows Mobile 2003 Host PDA , the desktop prompts "Installing Applications" dialog. Select "No" at the prompt, and Select SD Card as the Destination Media of installation.
7	If it is Windows Mobile 2005 Host PDA , PDA prompts "Choose a location to Install...". Select SD Card as the installation location
8	Follow the instructions on the rest of the installation prompts to finish.

Case 3: Upgrade the MC toolkit software only

To update the MC Toolkit software on the existing 256 MB Memory Card on the Host PDA, follow the steps in Table 3.

Table 3 Installation Instructions

Step	Action
1	<p>If the Host PDA has any or all of the previously installed following programs, follow the steps below to remove these programs from the PDA.</p> <ul style="list-style-type: none"> A. Honeywell MC Toolkit B. MC Toolkit C. SDC D. Honeywell SDC E. CFG_MCT F. Honeywell CFG_MCT <p>Steps:</p> <ul style="list-style-type: none"> a. Select Start/Settings/System/Memory/Remove Programs b. Select the above programs one by one (If a program is not listed, that means it was not installed on this PDA before) c. Select Remove, select Yes on the Remove Program dialog d. Soft Reset the PDA
2	Setup ActiveSync connection with between the PDA and the Desktop
3	<p>If the desktop PC has any or all of the previously installed following programs, follow the steps below to remove these programs from the PC.</p> <ul style="list-style-type: none"> A. Honeywell MC Toolkit B. MC Toolkit C. SDC

Step	Action
	D. Honeywell SDC E. CFG_MCT F. Honeywell CFG_MCT Steps: <ol style="list-style-type: none"> Select Start/Settings/Control Panel/Add Remove Programs Select the above programs one by one (If a program is not listed, that means it was not installed on this PC before) Select Change/Remove On the "Welcome Dialog" select "Remove", hit Next. Click Yes on "Do you want to completely remove..." prompt.
4	From the Web site listed under Summary Save the following item into your pc <ol style="list-style-type: none"> MC toolkit Installation setup Follow the Steps below: <ol style="list-style-type: none"> Unzip item 1 to a folder on the PC (ex: MCT) - Setup.exe file will be extracted With the Activesync connection in place, Run Setup.exe saved in Step a. on the PC
5	Follow the instruction 6 or 7 depending upon the Host PDA OS Version
6	If it is Windows Mobile 2003 Host PDA , the desktop prompts "Installing Applications" dialog. Select "No" at the prompt, and Select SD Card as the Destination Media of installation.
7	If it is Windows Mobile 2005 Host PDA , PDA prompts "Choose a location to Install...". Select SD Card as the installation location
8	Follow the instructions on the rest of the installation prompts to finish.

Case 3: Upgrade the DD files only

To update the MC Toolkit DD files on the existing 256 MB Memory Card on the Host PDA, follow the steps in Table 4.

Table 4 Installation Instructions

Step	Action
1	Setup ActiveSync connection between the Host PDA and the Desktop
2	From the Web site listed under Summary Save the following item into your pc <ol style="list-style-type: none"> MCToolkit DD File – Qx/200x Follow the Steps below:

Step**Action**

- a. Unzip item 1 to a folder named Release on the PC.
 - b. With the Activesync connection in place between PC and the PDA, replace the entire Release folder under Honeywell SDC and SDC on the PDA with the one on the PC (PDA path: Start/Programs/File Explorer/My Device/SD Card /)
-